

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Table: TBL_INSTALLATION					
Installation ID	INST_INSTALLATION_ID	Unique identifier for each installation	TBL_INSTALLATION	Numeric	12
Property Type	INST_GOV'T_OWNED_LEASED_TRUST	Indicate "G" when reporting data on Government-owned installations, an "L" when reporting data on leased installations, or a "T" when reporting data on trusts	TBL_INSTALLATION	Alpha	1
Agency Code	INST_AGENCY_CODE	Two digits identify the agency	TBL_INSTALLATION	Numeric	2
Bureau Code	INST_BUREAU_CODE	Two digits identify the bureau within the agency	TBL_INSTALLATION	Numeric	2
Installation Number	INST_INSTALLATION_NUM	Five-digit number identifying the headquarters location of the installation and parts of an installation located separately from the headquarters installation.	TBL_INSTALLATION	Alpha/Numeric	5
Site Code	INST_SITE_CODE	The last two numbers, are the suffix. A sub-installation is part of an installation identified by a different Geographic Location Code than that of the headquarters installation. For sub-installations, sequentially assign each suffix beginning with "01" and report separately. Enter "00" for the headquarters installation before entering additional suffixes.	TBL_INSTALLATION	Alpha/Numeric	2
Installation Name	INST_INSTALLATION_NAME	A name of an installation not exceeding 200 character spaces, including blank spaces	TBL_INSTALLATION	Alpha	200
Address 1	INST_ADDRESS_LINE_1	The installation's street address	TBL_INSTALLATION	Alpha/Numeric	200
Address 2	INST_ADDRESS_LINE_2	Additional address information	TBL_INSTALLATION	Alpha/Numeric	200
County	INST_COUNTY	The name of the county, U.S. territory, or foreign country where the installation is located	TBL_INSTALLATION	Alpha	100
City	INST_CITY	The city or town where the installation is located	TBL_INSTALLATION	Alpha	100
State	INST_STATE_ABBR	The name of the State (inside United States) or Continent (outside United States) where the installation is located	TBL_INSTALLATION	Alpha	2
Country	INST_COUNTRY_CODE	The name of the county, U.S. territory, or foreign country where the installation is located	TBL_INSTALLATION	Alpha	2

2 3 allowed but only 2 used

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Zip Code	INST_ZIP_CODE	The installation headquarter's primary zip code and, if known, the additional four-digit zip code suffix. If unknown, leave blank the space for the additional four-digit zip code suffix.	TBL_INSTALLATION	Numeric	10
Zone	INST_ZONE_ID	GSA Disposal's Office assigned code	TBL_INSTALLATION	Numeric	2
Region	INST_REGION_ID	GSA PBS assigned region id	TBL_INSTALLATION	Numeric	2
Historical Indicator	INST_HIST_INDICATOR	Indicate if the installation or any portion of the installation is listed on or eligible for inclusion on the National Register of Historic Places	TBL_INSTALLATION	Alpha	1
Last Survey Date	INST_LAST_SURVEY_DATE	The month and year of last survey	TBL_INSTALLATION	Date	Date
Status	INST_STATUS_ID	Indicate active, baseline, deferred, exempt or rescheduled as determined by GSA	TBL_INSTALLATION	Numeric	3
Next Survey Date	INST_NEXT_SURVEY_DATE	The month and year of the next scheduled survey	TBL_INSTALLATION	Date	Date
Mission Change	INST_MISSION_CHANGE	Indicate whether the installation mission or use has changed	TBL_INSTALLATION	Alpha	1
Anticipated Excess Date	INST_ANTICIPATED_EXCESS_DATE	Enter the month and year of the anticipated excess date	TBL_INSTALLATION	Date	Date
GSA Assistance Needed	INST_GSA_ASSIST_NEEDED	GSA provides assistance in the following areas: utilization surveys, relocation analyses, preparation of Standard Form 118 (Report of Excess), and disposing of installations under holding agency authority	TBL_INSTALLATION	Alpha	1
WWI Remarks	INST_WWI_REMARKS	Explanations for changes to records in the report, such as capital improvements, write-offs, and refinement of data.	TBL_INSTALLATION	Alpha	4000
Mission	INST_MISSION	Indicates the installation's purpose	TBL_INSTALLATION	Alpha	4000
Description	INST_DESCRIPTION	Description of the installation's mission	TBL_INSTALLATION	Alpha	4000
Estimated Current Value	INST_EST_CUR_VALUE	An estimate of the installation's current value (expressed in thousands of dollars). Your estimate may come from a professional appraisal or other reasonable source	TBL_INSTALLATION	Numeric	12

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Highest and Best Use	INST_HIGH_BEST_USE_ID	This code indicates how most of the installation is used.	TBL_INSTALLATION	Numeric	3
Excess Indicator	INST_EXCESS_IND	Use E if any part of a property is in excess of the agency's need.	TBL_INSTALLATION	Alpha	1
Number of Leases	INST_LEASE_NUM_REPORTED	Number of leases at this site	TBL_INSTALLATION	Numeric	4
Lease Effective Date	INST_LEASE_EFFECTIVE_DATE	The date on which the lease went into effect.	TBL_INSTALLATION	Date	Date
Lease Expiration Date	INST_LEASE_EXPIRATION_DATE	The date on which the lease expires.	TBL_INSTALLATION	Date	Date
Renewal Options	INST_LEASE_RENEWAL_YEARS	Describes the number of option years attached to this lease.	TBL_INSTALLATION	Numeric	2
Annual Rent Amount	INST_LEASE_ANNUAL_RENT	Indicates annual rental amount for this lease	TBL_INSTALLATION	Numeric	12
Lease for Structure	INST_LEASE_STRUC_FAC_IND	Indicates that this lease is for a structure	TBL_INSTALLATION	Alpha	1
Record Create Date	INST_CREATE_DATE	Date record created	TBL_INSTALLATION	Date	Date
Record Created By	INST_CREATE_BY_ID	Identifier of person creating record	TBL_INSTALLATION	Numeric	12
Record Update Date	INST_UPDATE_DATE	Date record updated	TBL_INSTALLATION	Date	Date
Record Updated By	INST_UPDATE_BY_ID	Identifier of person updating record	TBL_INSTALLATION	Numeric	12
Record to be Deleted	INST_DELETED	Marks record to be deleted	TBL_INSTALLATION	Alpha	1
Record Deleted By	INST_DELETE_BY_ID	Identifier of person marking record delete	TBL_INSTALLATION	Numeric	12
Delete Comments	INST_DELETE_CMNTS	Reason for delete	TBL_INSTALLATION	Alpha	4000
Installation Origin ID	INST_ORIGIN_ID	Assigned by system indicating source of data (website vs 1166 upload)	TBL_INSTALLATION	Numeric	3
Delete Date	INST_DELETE_DATE	Date record is deleted	TBL_INSTALLATION	Date	Date
State Code	INST_GEOLOC_STATE	Field allows a maximum of 2 alphanumeric characters for the state code of the state in which the site or property is located	TBL_INSTALLATION	Numeric	2
City Code	INST_GEOLOC_CITY	Field allows a maximum of 4 alphanumeric characters for the city code of the city in which the property is located.	TBL_INSTALLATION	Numeric	4
County/Country Code	INST_GEOLOC_CNTY_OR_CNTRY	Field allows a maximum of 3 alphanumeric characters for the county code of the county in which the property is located.	TBL_INSTALLATION	Numeric	3
Table: TBL_LAND					
Land Installation ID	LAND_INSTALLATION_ID	Equal to the Inst_Installation_ID of the installation to which this land belongs	TBL_LAND	Numeric	12

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Land Usage Code	LAND_USAGE_CODE	Two-digit code numbers indicate the land's predominant use:	TBL_LAND	Numeric	2
Land origin ID	LAND_ORIGIN_ID	Assigned by system indicating source of data (website vs 1166 upload)	TBL_LAND	Numeric	3
Land Transaction Code	LAND_TRANS_CODE_ID	Indicates whether record is new, change or delete	TBL_LAND	Numeric	3
Land Acquisition code	LAND_ACQ_CODE_ID	Indicates whether land is Public Domain, purchase, donation, etc, or long term interest	TBL_LAND	Numeric	3
First Date of Acquisition	LAND_ACQ_FROM	Date Federal Government first acquired land at this installation	TBL_LAND	Date	Date
Last Date of Acquisition	LAND_ACQ_TO	Date Federal Government acquired land last at this installation	TBL_LAND	Date	Date
Acquisition Cost	LAND_ACQ_COST	The total acquisition cost (expressed in thousands of dollars) of the land, including capitalized improvements	TBL_LAND	Numeric	12
Estimated Indicator	LAND_EST_COST_IND	Indicates that the land acquisition cost is an estimate if the actual acquisition cost is unknown.	TBL_LAND	Alpha	1
Negligible cost indicator	LAND_NEG_COST_IND	Indicates the total acquisition cost for the land is less than \$500	TBL_LAND	Alpha	1
Urban Acres	LAND_URBAN_ACRES	The land area to the nearest tenth of an acre for land within the boundaries of a densely populated area of 2,500 inhabitants or more	TBL_LAND	Numeric	14,2
Rural Acres	LAND_RURAL_ACRES	The land area to the nearest tenth of an acre for land not classified as urban	TBL_LAND	Numeric	14,2
Table: TBL_BLDG					
Building Installation ID	BLDG_INSTALLATION_ID	Equal to the Inst_Installation_ID of the installation to which this building belongs	TBL_BLDG	Numeric	12
Building Usage Code	BLDG_USAGE_CODE	Two-digit code numbers indicate a building's predominant use	TBL_BLDG	Numeric	2
Bldg origin ID	BLDG_ORIGIN_ID	Assigned by system indicating source of data (website vs 1166 upload)	TBL_BLDG	Numeric	3

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Building Transaction Code	BLDG_TRANS_CODE_ID	Indicates whether record is new, change or delete	TBL_BLDG	Numeric	3
First date of Acquisition	BLDG_ACQ_FROM	Date Federal Government first acquired a building at this installation	TBL_BLDG	Date	Date
Last Date of Acquisition	BLDG_ACQ_TO	Date Federal Government acquired a building last at this installation	TBL_BLDG	Date	Date
Building Acquisition Cost	BLDG_ACQ_COST	The total acquisition cost (expressed in thousands of dollars) of the building, including capitalized improvements	TBL_BLDG	Numeric	12
Estimated Cost Indicator	BLDG_EST_COST_IND	Indicates that the building acquisition cost is an estimate if the actual acquisition cost is unknown.	TBL_BLDG	Alpha	1
Negligible Cost Indicator	BLDG_NEG_COST_IND	Indicates the total acquisition cost for the building is less than \$500	TBL_BLDG	Alpha	1
Number of Buildings	BLDG_NUM_BLD	Number of buildings for each applicable usage code at this installation.	TBL_BLDG	Numeric	12
Building Gross Square Feet	BLDG_BLD_SQFT	The gross square footage (measurement of building's outside dimensions) for each building class reported.	TBL_BLDG	Numeric	14,2
Table: TBL_STRCT					
Structure Installation ID	STRCT_INSTALLATION_ID	Equal to the Inst_Installation_ID of the installation to which this structure belongs	TBL_STRCT	Numeric	12
Structure Usage Code	STRCT_USAGE_CODE	Two-digit code numbers indicate a structure's predominant use	TBL_STRCT	Numeric	2
Structure Origin ID	STRCT_ORIGIN_ID	Assigned by system indicating source of data (website vs 1166 upload)	TBL_STRCT	Numeric	3
Structure Transaction Code	STRCT_TRANS_CODE_ID	Indicates whether record is new, change or delete	TBL_STRCT	Numeric	3

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Structure Acquisition Cost	STRCT_ACQ_COST	The total acquisition cost (expressed in thousands of dollars) of the structure, including capitalized improvements	TBL_STRCT	Numeric	12
Estimated Cost Indicator	STRCT_EST_COST_IND	Indicates that the structure acquisition cost is an estimate if the actual acquisition cost is unknown.	TBL_STRCT	Alpha	1
Negligible Cost Indicator	STRCT_NEG_COST_IND	Indicates the total acquisition cost for the structure is less than \$500	TBL_STRCT	Alpha	1
Table: TBL_CONG_DISTRICT					
Congressional Installation ID	CONG_INSTALLATION_ID	Equal to the Inst_Installation_ID of the installation to which this congressional district belongs	TBL_CONG_DISTRICT	Numeric	3
State Abbreviation	CONG_STATE_ABBR	State Abbreviation	TBL_CONG_DISTRICT	Alpha	2
Congressional District	CONG_CONG_DISTRICT	The Congressional districts that the installation falls within.	TBL_CONG_DISTRICT	Numeric	20

Additional Tables:

Table: TBL_AGENCY					
Agency Code	AGENCY_CODE	Two digits identify the agency	TBL_AGENCY	Alpha	2
Agency Name	AGENCY_NAME	Name of agency	TBL_AGENCY	Alpha	100
Table: TBL_BUREAU					
Bureau Code	BUREAU_CODE	Two digits identify the bureau within the agency	TBL_BUREAU	Alpha	2
Bureau Name	BUREAU_NAME	Name of bureau	TBL_BUREAU	Alpha	100
Bureau - Agency code	BUREAU_AGENCY_CODE		TBL_BUREAU	Alpha	2
Table: TBL_COUNTRY					
Country Code	CTRY_COUNTRY_CODE	Two digit country code	TBL_COUNTRY	Alpha	2
Country Name	CTRY_COUNTRY_NAME	Name of Country	TBL_COUNTRY	Alpha	100
Country Type	CTRY_COUNTRY_TYPE		TBL_COUNTRY	Alpha	55
Continent	CTRY_CONTINENT	Continent	TBL_COUNTRY	Alpha	20
Table: TBL_NEW_GEOLOC					
Unique Identifier	ID	Unique identifier	TBL_NEW_GEOLOC	Numeric	10
		U = United States, I = International, T = US Territory			
Territory	TERRITORY		TBL_NEW_GEOLOC	Alpha	1
State/Country Name	LOCATIONNAME	State or Country Name	TBL_NEW_GEOLOC	Alpha	255
State Code	STATECODE	State Code	TBL_NEW_GEOLOC	Alpha	255
City Name	CITYNAME	City Name	TBL_NEW_GEOLOC	Alpha	255
City Code	CITYCODE	City Code	TBL_NEW_GEOLOC	Alpha	255
Country Code	COUNTRYCODE	Country Code	TBL_NEW_GEOLOC	Alpha	255

Field Labels	Field Names	Field Definition	Field Location	Alpha/Numeric	Field Size
Table: TBL_PERSON					
Person ID	PERS_PERSON_ID	ID assigned to User	TBL_PERSON	Numeric	12
Login	PERS_LOGIN	Login assigned to User	TBL_PERSON	Alpha	20
First Name	PERS_FIRST_NAME	User's First Name	TBL_PERSON	Alpha	100
Last Name	PERS_LAST_NAME	User's Last Name	TBL_PERSON	Alpha	100
Access	PERS_ACCESS_LEVEL	0 = READ ONLY, 1 = READ/WRITE, 99 = ADMIN	TBL_PERSON	Numeric	2
Email Address	PERS_EMAIL_ADDRESS	User's Email address	TBL_PERSON	Alpha	100
Phone Number	PERS_PHONE_NUMBER	User's Phone Number	TBL_PERSON	Alpha	15
Address	PERS_ADDRESS_LINE_1	User's Address	TBL_PERSON	Alpha	200
Additional Address Information	PERS_ADDRESS_LINE_2	Additional Address Information	TBL_PERSON	Alpha	200
Zip Code	PERS_ZIP_CODE	User's Zip Code	TBL_PERSON	Alpha	10
City	PERS_CITY	User's City	TBL_PERSON	Alpha	100
State	PERS_STATE_ABBR	User's State	TBL_PERSON	Alpha	18
Update Date	PERS_UPDATE_DATE	Date User Updated	TBL_PERSON	Date	Date
Create Date	PERS_CREATE_DATE	Date User Created	TBL_PERSON	Date	Date
Password	PERS_PASSWORD	User's Password	TBL_PERSON	Alpha	20
Most Recent Login	PERS_MOST_RECENT_LOGIN	Date of User's Most Recent Login	TBL_PERSON	Date	Date
Number of Logins	PERS_NUM_LOGINS	Number of Logins for this user	TBL_PERSON	Numeric	10
Agency ID	PERS_AGENCY_ID	User's Agency ID	TBL_PERSON	Alpha	2
Bureau ID	PERS_BUREAU_ID	User's Bureau ID	TBL_PERSON	Alpha	2
Table: TBL_BLDG_USAGE_CODE					
Building Usage Code	USAGE_CODE	Building Usage Code	TBL_BLDG_USAGE_CODE	Alpha	2
Building Usage Name	USAGE_NAME	Building Usage Name	TBL_BLDG_USAGE_CODE	Alpha	100
Table: TBL_LAND_USAGE_CODE					
Land Usage Code	USAGE_CODE	Land Usage Code	TBL_LAND_USAGE_CODE	Alpha	2
Land Usage Name	USAGE_NAME	Land Usage Name	TBL_LAND_USAGE_CODE	Alpha	100
Table: TBL_STRCT_USAGE_CODE					
Structure Usage Code	USAGE_CODE	Structure Usage Code	TBL_STRCT_USAGE_CODE	Alpha	2
Structure Usage Name	USAGE_NAME	Structure Usage Name	TBL_STRCT_USAGE_CODE	Alpha	100